



GPS Tracking System User's Manual *i-988M3*

Smartphone one key control



GPS Tracking System

www.debeztgps.com
Safe, Simple and Efficient

Diimport/Diedar: BEYOND TRADING SDN.BHD.
Address: No.37-39-41-43, Jalan Kasuarina 5/KS 7, Bandar Botanic, 41200 Klang,
Selangor Darul Ehsan, West Malaysia.
Tel: +603-3325 2255 (hunting line) Fax: +603-3325 1155
Email: betrading2003@yahoo.com Website: www.beyond.com.my



www.debeztgps.com

Table of contents

1. Product' s features.....	1
2. Product' s overview.....	1
3. Product components.....	2
4. Operation	3
5. Device's socket connection diagram	11
6. Using the web base enquiry portal for positioning and enquiry.....	12
7. Notes for the battery and battery charger.....	20
8. Matters for attention.....	20
9. Technical data.....	21


GPS Tracking System

1. Product' s features

GPS Tracking System is a multi-function tracking device, having functions such as positioning and Anti-theft. The device can be used by placing it inside a vehicle for positioning tracking.

Please read carefully this operating manual for maximising the usage of the product. Please keep this manual in safe custody for future use.

2. Product's overview



3.Product components



Main unit of the GPS Positioning device



Polymer rechargeable battery



Socket connection wires

4.Operation

4.1 Installing the SIM card

The SIM card must be able to send and receive SMS text message, with caller display function enabled and be able connecting to GPRS.

- A. Before inserting the SIM card, please make sure that the device is switched off and is not connected to in-car battery charger.
- B. The SIM card slot can be found once the battery cover and the rechargeable battery is removed.
- C. Insert the SIM card inside the SIM card slot and lock it up.



4.2 Installing the battery

Install the battery by connecting the plug of battery to the power jack of the system.



4.3 Switch on/off the device

To turn on: when GPS is off, press and hold the Power button for 2 seconds, GPS's COM indicator light (Red) keeps shining for 3 seconds and flashes 3 times, system has been turned on.

To turn off: When GPS is off, press and hold the Power button for 2 seconds, GPS's COM indicator light (Red) keeps shining for 5 seconds, system has been turned off.

Remark:The device will not be reacted to any key pressing within 30 seconds after the device is being switching on (or within 30 seconds while searching the GSM signal).



4.4 Status of Indicators

- A. GSM Indicator (Blue):** Indicator for telecommunication signal. Once connected to the GSM network, the indicator should flash once in every 3 seconds.
- B. GPS Indicator (Green):** Indicator will be flashing while searching satellite signal. Once connected, the indicator will flash once in every 5 seconds.
- C. COM Indicator (Red):** Indicator will flash once in every 5 seconds if the device is in Anti-Theft alert warning mode. If deactivated, the indicator will not flash.

4.5 Setting the monitoring mobile phone

The monitoring mobile phone will be used to set up and modify the system setting. The monitoring mobile phone will receive SMS text message warning alert being sent from the GPS device. Before setting up the system's monitoring functions, the user must register at least two monitoring mobile phone numbers (maximum registered mobile phone number is three). Write a SMS text message to the device's SIM card phone number through the primary phone number (the first mobile phone number). **The password must be in six digits format and the default password is 999999.**

The device's SIM card phone number is the recipient of the following SMS text message.

- A.**Setting the primary mobile phone number: It is suggested that the primary mobile phone number be the usual driver of the vehicle.
SMS text Format: **Password,100,Primary mobile phone number**
Example: **999999,100,0198812345**
Returned SMS text message: **Connection to #1 done**
- B.**Setting up the second mobile phone number: It is suggested that the second mobile phone number be a close relative of the usual driver.
SMS text Format: **Password,200,Second mobile phone number**
Example: **999999,200,0198823456**
Returned SMS text message: **Connection to #2 done**
- C.**Setting up the third mobile phone number: It is suggested that the third mobile phone number be a close relative of the usual driver.
SMS text Format: **Password,300,Third mobile phone number**
Example: **999999,300,0198834567**
Returned SMS text message: **Connection to #3 done**

Remark: The input mode must be in English for entering the full content of the SMS text message, otherwise, the set up will not be successful. The same apply to all the other system settings.

4.6 Changing the device's password

Write a SMS text message to the SIM card phone number through the primary mobile phone number.

SMS text Format: **Old password,500,New password**(password must be 6 digits)

Example: **999999,500,123456**

Returned SMS text message: **New password changed to 123456**

Remark: Each device will have one set of password only. Once the password is changed, the new password must be used for all the other device's set up or modification. (The changing of device's password can only be done by the primary mobile phone number, the other registered mobile phones have no right to make such change).

4.7 Reset to default factory setting

If the user has forgotten the new password, the user can send the SIM card's phone number through the primary mobile phone number a SMS text message to reset the device to the default factory setting.

Send the SMS text message: **800**

Returned two SMS text messages: **Reset to factory default setting** and **System working properly, please verify the SIM card balance**

Remark:Please use this function carefully as the function will reset the device to default factory setting! All previous device setting and data will be lost, please set up the device again. This setting is open to the primary mobile phone number only. The other registered mobile phone numbers are not authtorised to use the function.

4.8 Actively query and wake up the device in sleep

After stopping driving for 4 minutes, if no shock happens, the device will automatically enter the power-saving sleep mode. It is convenient for the owner to wake up the device and positioning the monitored vehicle at any time (when the winding of device is connected with the power supply in the vehicle, the system will enter a 24-hour working).

Send the SIM card's phone number through the primary mobile phone number a

SMS text message to enquiry the device's status.

Send the SMS text message: **600**

Returned two SMS text messages: **The current specific address, driving speed, direction, voltage and other values about the vehicle.**

Remark:The enquiry must be made through the primary mobile phone number. The other registered mobile phone numbers have no right to make such enquiry.

4.9 Activate/Deactivate the Anti-Theft function

A. Activation/Deactivation by sending SMS text message.

Activation: Send to the SIM card phone number through the primary mobile phone number a SMS text message.

Send the SMS text message: **111**

Returned SMS text message: **System activated**

Deactivation: Send to the SIM card phone number through the primary mobile phone number a SMS text message.

Send the SMS text message: **112**

Returned SMS text message: **System deactivated**

B. Activation/Deactivation by pressing the “R” button (It is recommended if the device is being used by person other than the usual driver)

Activation: Press the “R” button for 2 seconds, COM indicator light(Red) keeps shining for 1 second and it will then be in activation mode after 30 seconds.

Deactivation: Press the “R” button again for 2 seconds, COM indicator light (Red) then will flash twice and it will then be in deactivation mode.

C. Arming and disarming of car remote controller (Device must be connected onto the line of central control door lock, please refer to Device's socket connection diagram)

Arming: When user press the door-locking key, the system enters the arming state.

Disarming: When user press the door-opening key, the system enters the disarming state.

4.10 Monitoring Defense and Door Lock Simultaneously

Users can use the original remote control of car door to setting up and withdraw alarm simultaneously for the system and vehicle.

Setting up alarm simultaneously:Send to the SIM card phone number through the primary mobile phone number a SMS text message.

Send the SMS text message: **122**

Returned SMS text message: **Alarm has been turned on in-phase.**

Withdraw alarm simultaneously:Send to the SIM card phone number through the primary mobile phone number a SMS text message.

Send the SMS text message: **123**

Returned SMS text message: **Alarm has been released in-phase.**

Remark:

1. In order to configure the car monitoring and door lock to synchronize, the central lock inside the car alarm (original or retrofit) must be wired up.

2. When the synchronization of the car lock is achieved, you can only lock/ unlock the car using the original car remote control. Calling, texting or pressing the key will no longer be available for locking / unlocking the car.

4.11 Anti-theft warning alert by SMS/GPRS

The device will release alert message for the events of unlawful door open, unlawful ACC ignition start and abnormal vehicle movement. If any one of these events is detected, the device will release warning alert to the primary mobile phone number a SMS text message and GPRS signal to the web base enquiry portal.

A. Alert for unlawful door open

When the device is activated (the socket connection wires are properly connected for door open detection), in the case when unlawful door open is detected, the device will send to the primary mobile phone number two SMS text messages:

Alert! Abnormal door opened .the latitude and longitude .The device will also send the same message to the web base enquiry portal by GPRS signal.

B. Alert for unlawful ACC ignition start

When the device is activated (the device is properly connected to the ACC ignition device), in the case when unlawful ACC ignition start is detected, the device will

send to the primary mobile phone number two SMS text messages: **Alert! Abnormal start detected.the latitude and longitude** . The device will also send the same message to the web base enquiry portal by GPRS signal.

C. Abnormal vehicle movement

In the case if there is notable vibration detected and the vehicle is moving for more than 30 seconds, the red indicator will be flashing if the device is in activation mode. The device will send to the primary mobile phone number two SMS text messages: **Alert! Abnormal movement detected.the latitude and longitude** . The device will also send the same message to the web base enquiry portal by GPRS signal

4.12 SOS emergency call by SMS text message/GPRS

By pressing the “SOS” button located at the side of the device or the “SOS” button connected with the device socket wire for two seconds, the device red indicator will be flashing. Immediately after that, the device will send to second and third registered mobile phone number two SMS text messages: **Emergency, please check. the latitude and longitude**. The device will also send the same message to the web base enquiry portal by GPRS signal.

Remark: After pressing the “SOS” button to call for help, the user will have to wait until the device has completely sent the previous “SOS” alert text message before he can make the second “SOS” emergency call, otherwise the “SOS” call will not be validated.

4.13 Region-fencing warning

The setting for region-fencing must be done through marking the pre-determined region at the online map integrated with the web base enquiry portal. Once the region is determined and the vehicle is driving in/out of the pre-determined region, the device will send to the primary telephone number a SMS text message:**Vehicle moved outside the monitoring region. the latitude and longitude**. The device will also send the send message to the web base enquiry portal by GPRS signal.

Remark: The region-fencing can only be determined or cancelled through the web base enquiry portal. Region-fencing will remain function until it is being deactivated. (Please deactivate the function if region-fencing is not required, this will help save the SIM card’s SMS text message cost).

4.14 Speeding alert

The speeding limit can be determined through the web base enquiry portal. When the vehicle is travelling above the pre-determined speed limit, the device will send to the primary mobile phone number a SMS text message: **Vehicles Speeding. the latitude and longitude** . The device will also send the same message to the web base enquiry portal by GPRS signal.

Remark: The speeding alert can only be activated/deactivated through the web base enquiry portal. Speeding alert will remain function until it is being deactivated. (Please deactivate the function if speed alert is not required, this will help save the SIM card’s SMS text message cost.)

4.15 Power level alert through SMS text message

When the remaining battery power level is lesser than 20%, the device will send to the primary mobile phone number a SMS text message: **Power level is less than 20%, pls recharge battery**. If the remaining battery power level is lesser than 10%, the device will send to the primary mobile phone number a SMS text message: **Power consumption less than 10%, must recharge battery now**.

4.16 Email Alarm Function

After the users setting the email alarm function on monitoring platform through computer,all the alarm message from the device will sent to the appointment email address.(Please reference the operation manual page18, email alarm setting)

4.17 Function of Remote Flameout

When a vehicle is abnormal and gives an alarm, the user can start the function of remote flameout for the vehicle by monitoring platform, and the vehicle will automatically shut down engine.

Flameout Settings: In the operation menu of platform, click “Engine Flameout” to pop up the settings interface. After entering password and confirming, click the Enable key to start the remote flameout for the vehicles. After that, the vehicle will automatically shut down engine (After setting successfully, the platform will display the information of Remote Flameout Has Been Set for Vehicle).

Cancel Flameout: In the operation menu of platform, click “Cancel Engine Flameout” to pop up the settings interface,input the password of device and confirm this operation.

Remark:

1. Vehicles must be connected to the ACC wire group can be achieved remotely turn off features.
2. After user activate flameout function, vehicles will start up flameout in 1 minute, it make the oil-circuit flameout or power control flameout for a moving vehicle, it will likely lead to vehicles can not normal safe driving, to ensure the safety of vehicles traveling, we strongly recommend that users turn off their engines after parking the vehicle

Special Note:

If there is any security problems and accidents because of using the FLAMEOUT function, it has nothing to do with the company.

4.18 System alarm for power failure

After the equipment is connected with vehicle power, when a power failure occurs, the system will automatically send two SMS to the monitoring mobile phone: System power failure, the latitude and longitude and The current specific address, driving speed, direction, and other values about the vehicle.


5. Device's socket connection diagram

▲ Selection of door triggering mode




Remark: Upon installation, please select the proper triggering mode in accordance with the make and model of the vehicle.


▲ Positive door trigger wiring



▲ Negative door trigger wiring



▲ ACC wire connection



SOS switch

Ground connection

Connection to positive of the battery pack


Take away the battery cover to select the door triggering mode.

When door trigger jumper is selected "Door-", it represents that the door triggering mode is selected as negative. On the other hand, if jumper is selected "Door+", then the door triggering mode is selected as positive.


Upon installation, please select the door triggering mode in accordance with the make and model of the vehicle. The default factory setting of the triggering mode is "Door-" and representing that the door triggering is negative.

Remark: When the system is to be connected to DC12V/24V+/- line of vehicle, make sure to connect the trigger line of ACC to the trigger line of vehicle, otherwise the system will not work properly.

▲ Oil-channel flameout wiring





▲ Engine power-off wiring



Please be mind to use of the engine flameout function

▲ Connecting with door lock in-phase




6.Using the web base enquiry portal for positioning and enquiry

6.1 Logging into the server

Logging into the web site, www.debeztgps.com, the interface for signing into the GPS vehicle enquiry management device will pop up, fill in group name, user name, sign-in password and the security code. Once properly done, the interface for positioning enquiry and monitoring will then be signed in.

Remark: Individual user should select “VIP” user. If the portal is not in use for more than one hour, the device will log-off automatically. User must log-in again for accessing the portal.



6.2 Operating the function interface


User can use different functions at the service platform for operation or inquiry about information. If the user is unfamiliar with operation, he or she may consult the operation illustration at the control platform.

GPS vehicle monitoring and management portal is a free open platform. User can use it free of charge. The weather condition and external environmental factors could have impact on the actual location of the vehicle against the coordinate as shown on the monitoring map, or the driving track against the actual road map. It is also possible that the portal has not received accurate map data at any given time. User could also find discrepancy on the actual location of buildings, road condition and other relevance information against the data that you may obtain from the map. User will solely held responsible for liability of any kind caused by the use of data or information obtained from using the map provided by Google. Google will not be liable for any claim or damages, whether directly or indirectly, caused by the inaccurate data/information.

6.3 Operation illustration at the control platform



When login to the website, www.debeztgps.com, please fill in group ID, user ID, password & security code correctly for successful login.



Select the vehicle that you like to make the enquiry from the list of registered vehicles.



This box displays the instantaneous status, direction, address, longitude and latitude and equipment power of the vehicles.

Set Status	
Set Status	
Tracking:Nothing	
Speed Limit:Nothing	
Region Defend:Nothing	

This box displays the setup status of continuous positions, speed limits and zone arming.

Auto Center	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Information/status of the selected vehicle will then be locked up and displayed at the map.

Normal show	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Once the vehicle lock up is released, the system will then be returned to the normal mode.

Cancel Track	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Continuous positioning function will be terminated.

Speed Limit	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Setting up the speed limit in which the vehicle can travel. The system will send warning alert SMS text message to the user if it has been travelled above the speed limit.

Cancel Limit	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Cancelling the setting for speed limitation and the system will stop sending alert message to the user.

Show Trace	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Displaying the real time tracking in which the vehicle is being travelled.

Hide Trace	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout


The real time tracking in which the vehicle is being travelled will be hidden.

Tracking	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

The positioned equipment is subject to continuous positioning according to the distance or interval set for the equipment.

Region Defend	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout


Once the function for region-fencing is activated, the system will send alert message whenever the vehicle is driving in or out of the determined region/area.




Under the region defend, an area selection window will pop out, click on the area button above the map, and point the cursor on two positions and click out a rectangular region, then confirm the drawn region by click on set tab to complete the geo-fencing process.

Cancel Defend	
Operation	
Auto Center	Normal Show
Show Trace	Hide Trace
Tracking	Cancel Track
Speed Limit	Cancel Limit
Region Defend	Cancel Defend
Engine Flameout	Cancel Engine Flameout

Deactivating all the settings that have been done previously.




Click "Engine Flameout" to pop up the settings interface. After entering password and confirming, click the Enable key to start the remote flameout for the vehicles. About 1 minute after apply the setting, information bar will show "Engine Flameout" to signal.



Click "Cancel Engine Flameout" to pop up the settings interface, input the password of device and confirm this operation. About 1 minute after apply the setting; the "Engine Flameout" signal will be cancelled.




Select the date and time required for inquiry. Click "Inquire", the historical tracks of vehicles traveling at this time section will be displayed on the map, and meanwhile, data about the longitude and latitude at places of vehicles in this time section will be displayed on the list.



Click "Play", the historical tracks of the vehicles inquired about on the map will be played back by frames.

Click "Export", the detailed historical track data about the vehicles inquired about will be opened or saved in the Excel file format.

Click "Clear", the data inquired, played back and exported as previously selected will be all deactivated.



Select the year, month and date required for inquiry about, and then click on Inquire, and the alarm data on this vehicle given on a designated date will be displayed at the lower part of the Inquire box.

Click "Clean" to be able to close the alarm data list.



The blue icon in the Google traffic map shows the vehicle's location. When device has not uploaded positioning data in 10 minutes, icon will turn grey. When device uploads alarm information, icon will turn red. When replaying the historic trace, icon will turn green.




The blue icon in the Google satellite map shows the vehicle's location. When device has not uploaded positioning data in 10 minutes, icon will turn grey. When device uploads alarm information, icon will turn red. When replaying the historic trace, icon will turn green.



Under the traffic map, click at the target place will show the satellite map window for comparison.



Under the satellite map, click at the target place will show the traffic map window for comparison.



The travelled distance can be measured on the Map. click "Measure", then click the position that will be measured on the map, double-click to end.




User can mark down customized place on Google map.


Click "Add POI", window for entering place of interest will pop up, an icon will also appear on the center of the map.

Drag the icon to location where you need to add the name of interest on the map, then enter words, click "Save" to show the added location.

Click the added location, then press "Delete" on the pop-out window, and confirm to delete added location.




Click on "management system", go to Vehicle Management System, click on "vehicle", select corresponding vehicle's license plate number to go to management interface and change vehicle's information.




Click on “Unit’s Status”, Select corresponding license plate number to the latest uploaded record, such as Longitude, Latitude, Speed, battery volume and others.




Click on “Initialization mileage”, select corresponding license plate number, enter the value of mileage, then click on “Submit” to set up initial mileage.




Enter the alarm receiving E-mails (up to 3 E-mails available) in the “E-mail 1,2,3” in vehicle’s information management, also TICK behind the square box. Click SAVE to apply E-mail alarm function.



Click “Driving” , select Date and Output Format (Html or Excel) on the pop-out window,click “Submit” to check vehicle’ s stopping location and driving location.




Click “Password” , the password modification interface will pop out on the screen. After the new and old passwords are filled in and confirmed, click “Save” to finish password modification.



By clicking the lower right hand corner of the window, the “Term of use” interface will be popped-up which show all the terms and conditions applicable for using the Web base enquiry portal.



Click on “Report” , go to Report window. Click on “Online” , select Type and Days. click on “Query” to check out online and offline devices.



Click on “Enquire Total Mileage” , select license plate number to enquire vehicle’s initial mileage and total mileage.



Click “Mileage” , select vehicle, date, output format (Html or Excel), then click “Submit” to check the driving distance of specific vehicle.



Click “Print”, the window’s content will be printed.

7. Notice for the battery

- A. The device should only use the rechargeable battery supplied by us. Using accessories manufactured by other third party could cause damage to the rechargeable battery such as battery leakage, overheat, explosion or fire.
- B. The performance of the battery could get weaker as the number of recharging is increased. Please replace the selected battery pack when it no longer provides acceptable performance or it cannot be recharged properly.
- C. Do not leave the device in extreme hot or cold places, this may deteriorate the battery performance.
- D. Please do not put the GPS device next to a microwave oven or high temperature facilities for avoiding events such as short circuit or causing fire.
- E. During summer time, please do not place the device at a place inside your vehicle which directly expose to sun-shine. There could be risk of explosion if the in-car temperature is higher than 70°C.
- F. Please do not use the device at a place containing highly flammable gas for avoiding device's malfunctions or causing fire.
- G. Please do not put the device, the rechargeable battery or the charger into fire or use the device and /or accessories at a place where there is water flowing.

8. Matters for attention

We are not liable for any claim against the Company if the device is failed to receive GPS signal due to the following circumstances:

- A. Geographical reasons (e.g. the vehicle is located at a basin, remote mountain area, etc).
- B. Surrounding environment (where the vehicle is surrounding with high rise buildings or the vehicle is travelling inside a tunnel).
- C. Building or construction, such as Power Station or Power Pole, which could interfering the receipt of GPS signal.
- D. Bad weather.
- E. If medal heat insulating window film and heat-insulation course are applied to the vehicle's glass window, it will affect and reduce the GPS reception of signal, also GPS may be unable to function properly. If GPS is unable to locate, please change the installed position of GPS.

9. Technical data

Polymer rechargeable battery: 3.7V 2500mAh

Air interface: GSM/GPRS/GPS

Supported frequencies: GSM850/900/1800/1900 MHz, GPS 1575.42 MHz

GPS sensitivity: -147dbm ~ - 159dbm

Ambient temperature: -35°C to 80°C

Working environment: Area with GSM/GPRS network coverage

Product size: 118x68x33mm

Product weight: 190g